

Electrical Symbols

General outlets

Ceiling Wall

-   Outlet
-   Electrical Outlet—for use only when a circle used alone might be confused with columns or other geometry
-   Fan Outlet
-   Lamp holder
-   Lamp holder with a pull switch
-   Clock outlet (specify voltage)

Receptacles

-  Duplex receptacle
-  Triplex receptacle
-  Weatherproof receptacle
-  240 V receptacle
-  Range receptacle
-  Switch and duplex receptacle
-  Ground-fault circuit interrupter receptacle
-  Split-wired receptacle
-  Special purpose receptacle
-  Floor receptacle

Switches

-  Single pole switch
-  Double pole switch
-  Three-way switch
-  Four-way switch
-  Key operated switch
-  Switch and pilot lamp
-  Circuit breaker
-  Weatherproof circuit breaker
-  Momentary contact switch
-  Weatherproof switch
-  Timer switch

Miscellaneous

-  Flush-mount panel
-  Surface-mount panel
-  Transformer
-  Surface-mount fluorescent fixture
-  Recessed fluorescent fixture
-  Telephone outlet
-  Wall mounted telephone outlet